

CompanySound

We are your voice. Be Heard.

How to change your message:

Follow these steps to add or remove files from your USB flash drive.

Step 1: Plug the USB flash drive into an available USB port on a any PC or MAC compatible computer. The flash drive should show up as a “Removable Disk ” on the computer.



Step 2: Drag ‘n ’ drop the file(s) to the USB flash drive. If removal of files are required then select the files and press the <delete> key on the keyboard.

Step 3: Remove the USB flash drive from the computer.

Step 4: Plug the USB flash drive into the Player for playback.

